

# INSTRUCTIONS

Your DAMPIT is made of the finest materials. With proper care it will give you years of good service.

DAMPIT is designed to fit inside your instrument, where it slowly releases moisture to create the proper humidity. Regular use of DAMPIT will protect your instrument from cracking and keep the pads from drying out.

1. Immerse DAMPIT in water about 20 seconds. (In hard water areas use softener or distilled water.)

2. Pinch end of DAMPIT to remove excess water. Gently wipe outer tube dry. Place inside the first joint of your instrument (and/or wing joint of bassoon). The tapered joint of the oboe and English horn permits only partial entry. Fold the balance of the DAMPIT alongside the first joint before closing the case. When DAMPIT is nearly dry repeat the above process.

Store your instrument in the coolest part of the room — away from radiators and heat registers. Use DAMPIT only during dry weather or central heating periods.

Follow DAMPIT Humidity Indicator directions carefully.

A rubber disc is enclosed for large woodwind instruments. Stretch disc over large button of DAMPIT.

THE ENCLOSED  
DAMPIT HUMIDITY INDICATOR  
WILL TELL YOU WHEN TO USE

## dampit®

The DAMPIT Humidity Indicator will show the percentage of humidity of your room. The numbered spots on the left will change color as the humidity changes. Determine the percentage of humidity by choosing the numbered spot most closely matching the color of the background panel on the right.

# PLAY SAFE USE DAMPIT

DAMPITS, INC., P.O. BOX 493, RADIO CITY STATION, NEW YORK, N. Y. 10019